

ALL SEASONS INDOOR COMPOSTER

COMPOSTING MADE EASY! Compost meat, bones, dairy and food scraps.



1 To get started - You will need the All Seasons Indoor Composter and All Seasons Bokashi.



2 First, lightly dust the bottom of your All Seasons Indoor Composter with All Seasons Bokashi. Be sure not to block the small holes in the bottom of the tray.



3 Before you add food scraps, chop everything into small pieces. You can use (small) bones, cheese, coffee grounds and meat as well as the fruits and vegetables.



4 Add food scraps to the bucket, in layers (up to 3").



5 Dust each layer with a healthy handful of Bokashi. When putting in meat, bones, cheese, coffee grounds or other hard to decompose materials, use more All Seasons Bokashi than normal.



6 Use a wooden spatula or spoon to mix the food scraps and All Seasons Bokashi. Once mixed, sprinkle a little more Bokashi on the top.



7 Minimize exposure to air by placing a plastic bag or plate over the top and press down. Leave in place until the next use.



8 Close lid tightly. Repeat steps 4-7 each time food scraps are added and All Seasons Indoor Composter is full.



9 Drain compost "tea" 2-3 days or as needed. Dilute the "tea" (one tbs./gallon of water). Use immediately on indoor plants or outside in the garden.

When the bucket is full, dig a hole in the yard and bury the compost. The composting process takes approximately 2 weeks in the summer and one month in the winter time.